


McMinnville Municipal Airport
Airport Layout Plan Report

**GLOSSARY OF
AVIATION TERMS**



Glossary of Aviation Terms



The following glossary of aviation terms was compiled from entries provided by David Miller, Century West Engineering; Chris Corich, W&H Pacific; and Gary Viehdorfer, Oregon Department of Aviation for use in aviation planning projects.

Agricultural Aviation – The use of fixed-wing or rotor-wing aircraft in the aerial application of agricultural products (i.e., fertilizers, pesticides, etc.).

Air Cargo - All commercial air express and air freight with the exception of airmail and parcel post.

Air Carrier - All regularly scheduled airline activity performed by airlines certificated in accordance with Federal Aviation Regulations (FAR Part 121 or 127).

Air Taxi - Operations of aircraft "for hire" for specific trips, commonly referred to as aircraft available for charter.

Aircraft Approach Category - A grouping of aircraft based on how fast they come in for landing. As a rule of thumb, slower approach speeds mean smaller airport dimensions and faster speeds mean larger dimensions from runway widths to the separation between runways and taxiways.

The aircraft approach categories are:

Category A - Speed less than 91 knots;

Category B - Speed 91 knots or more but less than 121 knots

Category C - Speed 121 knots or more but less than 141 knots

Category D - Speed 141 knots or more but less than 166 knots

Category E - Speed 166 knots or more

Aircraft Operation - A landing or takeoff is one operation. An aircraft that takes off and then lands creates two aircraft operations.

Aircraft Owners and Pilots Association (AOPA) – International aviation organization.

Airline - A scheduled air carrier certificated under Part 121 of the Federal Aviation Regulations.

Airplane Design Group - A grouping of airplanes based on wingspan. As with Approach Category, the wider the wingspan, the bigger the aircraft is, the more room it takes up for operating on an airport. The Airplane Design Groups are:

Group I: Up to, but not including 49 feet

Group II: 49 feet up to, but not including 79 feet

Group III: 79 feet up to, but not including 118 feet

Group IV: 118 feet up to, but not including 171 feet

Group V: 171 feet up to, but not including 214 feet

Group VI: 214 feet up to, but not including 262 feet

Airport - A landing area regularly used by aircraft for receiving or discharging passengers or cargo, including heliports and seaplane bases.

Airport Categories – The following categories are used to describe public use airports in Oregon. For additional information, see the **Oregon Aviation Plan**.

Category 1 – Commercial Airports

Category 2 – Business Aviation or High Activity General Aviation Airports

Category 3 – Regional General Aviation Airports

Category 4 – Community General Aviation Airports

Category 5 – Low Activity General Aviation Airports

Airport Improvement Program (AIP) - The funding program administered by the Federal Aviation Administration (FAA) with user fees which are dedicated to improvement of the national airport system. This program provides 90% of funding for eligible airport improvement projects. The local sponsor of the project (i.e., airport owner) has to come up with the remaining 10% known as the "match".

Airport Layout Plan (ALP) - The FAA approved drawing which shows the existing and anticipated layout of an airport for the next 20 years or so. An ALP is prepared using FAA design standards.

Airport Reference Code (ARC) - An FAA airport coding system. The system looks at the types of aircraft which use an airport most often and then based upon the characteristics of those airplanes (approach speed and wing span), assigns a code. The code is then used to determine how the airport is designed and what design standards are used. An airport designed for a Piper Cub (an aircraft in the A-I approach/design group) would take less room than a Boeing 747 (an aircraft in the D-V approach/design group).

Airports District Office (ADO) - The "local" office of the FAA that coordinates planning and construction projects. Staff in the ADO is typically assigned to a particular state, i.e., Oregon, Idaho, or Washington. The ADO for Oregon, Washington and Idaho is located in Renton, Washington.

Airspace - The area above the ground in which aircraft travel. It is divided into corridors, routes, and restricted zones for the control and safety of traffic.

Annual Service Volume (ASV) - An estimate of how many airplanes and airport can handle based upon the number and types of runways, the aircraft mix (big vs. small, etc), and the weather conditions. Annual service volume is one of the bench marks used to determine when an airport is getting so busy that a new runway or taxiway are needed.

Approach End of Runway - The end of the runway a pilot tries to land - could be thought of as the "landing end" of the runway. Which end a pilot uses depends upon the winds. Pilots almost always try and land into the wind and will line up on the runway that best aligns with the wind.

Approach Surface - Also FAR Part 77 Approach or Obstacle Clearance Approach - An imaginary (invisible) surface which rises off the ends of a runway which must be kept clear to provide airspace for an airplane to land or take off in. The size of the approach surface will vary depending upon how big and

how fast the airplanes are, and whether or not the runway has an instrument approach for landing in bad weather.

Apron - An area on an airport designated for the parking, loading, fueling, or servicing of aircraft (also referred to as tarmac and ramp).

ARFF - Aircraft Rescue and Fire Fighting, i.e., an on airport fire station.

Automated Weather Observation System (AWOS) - An automated weather observation system providing on-site weather data to support instrument approaches.

AVGAS - Gasoline used in airplanes with piston engines.

Avigation Easement - A form of limited property right purchase that establishes legal land use control prohibiting incompatible development of areas required for airports or airport-related purposes.

Based Aircraft - Aircraft stationed at an airport on an annual basis. Used as a measure of activity at an airport.

Capacity - A measure of the maximum number of aircraft operations that can be accommodated on the runways of an airport in an hour.

Charter - Operations of aircraft "for hire" for specific trips, commonly referred to an aircraft available for charter.

Conical Surface - One of the "FAR Part 77 "Imaginary" Surfaces. The conical surface extends outward and upward from the edge of the horizontal surface at a slope of 20:1 to a horizontal distance of 4,000 feet.

Critical Aircraft - Aircraft which controls one or more design items based on wingspan, approach speed and/or maximum certificated take off weight. The same aircraft may not be critical to all design items.

Crosswind - When used concerning wind conditions, the word means a wind not parallel to the runway or the path of an aircraft. Sometimes used in reference to a runway as in "runway 7/25 is the crosswind runway" meaning that it is not the runway normally used for the prevailing wind condition.

DNL - Day-night sound levels, a method of measuring noise exposure.

Enplanements - Domestic, territorial, and international revenue passengers who board an aircraft in the states in scheduled and non-scheduled service of aircraft in intrastate, interstate, and foreign commerce and includes intransit passengers (passengers on board international flights that transit an airport in the US for non-traffic purposes).

Entitlements - Distribution of Airport Improvement Plan (AIP) funds from the Airport & Airways Trust Fund to commercial service airport sponsors based on enplanements or cargo landed weights.

Federal Aviation Administration (FAA) - The FAA is the branch of the U.S. Department of Transportation that is responsible for the development of airports and air navigation systems.

FAR Part 77 - Federal Aviation Regulations which establish standards for determining obstructions in navigable airspace. FAR stands for Federal Aviation Regulations, Part 77 refers to the section in the regulations, i.e., #77. FAR Part 77 is commonly used to refer to imaginary surfaces, the primary, transitional, horizontal, conical, and approach surfaces. These surfaces vary with the size and type of airport.

Fixed Base Operator (FBO) - An individual or company located at an airport providing aviation services. Sometimes further defined as a "Full Service" FBO or a limited service. Full service FBOs typically provide a broad range of services (flight instruction, aircraft rental, charter, fueling, repair, etc) where a limited service FBO provides only one or two services (such as engine repair, or radio repair).

Fixed Wing - A plane with one or more "fixed wings" as opposed to a helicopter that is sometimes called a rotary wing aircraft.

Flight Service Station (FSS) - An office where a pilot can call (on the ground or in the air) to get weather and airport information. Flight plans are also filed with the FSS.

General Aviation (GA) - All civil (non-military) aviation operations other than scheduled air services and non-scheduled air transport operations for hire.

Global Positioning System (GPS) - GPS is a system of navigating which uses satellites to establish the location and altitude of an aircraft. The FAA recently embraced GPS as a system with potential for application in traveling from point A to point B as well as for use in making landing approaches.

High Intensity Runway Lights (HIRL) - High intensity (i.e., very bright) lights are used on instrument runways where landings are made in foggy weather. The bright runway lights help pilots to see the runway when visibility is poor.

Home Built Aircraft - An aircraft built by an amateur; not an FAA Certified factory built aircraft.

Horizontal Surface - One of the FAR Part 77 Imaginary (invisible) Surfaces. The horizontal surface is an imaginary flat surface 150 feet above the established airport elevation. Its perimeter is constructed by swinging arcs (circles) with a radius of 5,000 feet for all runways designated as utility or general; and 10,000 feet for all other runways from the center of each end of the primary surface and connecting the adjacent arc by straight lines. The resulting shape looks like a football stadium. It could also be described as a rectangle with half circles on each end with the runway in the middle.

Instrument Flight Rules (IFR) - IFR refers to the set of rules pilots must follow when they are flying in bad weather. Pilots are required to follow these rules when operating in controlled airspace with visibility (ability to see in front of themselves) of less than three miles and/or ceiling (a layer of clouds) lower than 1,000 feet.

Instrument Landing System (ILS)- An ILS is a system used to guide a plane in for a landing in bad weather. Sometimes referred to as a precision instrument approach, it is designed to provide an exact approach path for alignment and descent of aircraft. Generally consists of a localizer, glide slope, outer marker, middle marker, and approach lights. This type of precision instrument system is being replaced by Microwave Landing Systems (MLS).

Instrument Meteorological Conditions (IMC) - Meteorological conditions expressed in terms of visibility, distance from clouds, and ceiling less than minima specified for visual meteorological conditions.

Instrument Runway - A runway equipped with systems to help a pilot land in bad weather.

Itinerant Operation - All aircraft operations at an airport other than local, i.e., flights that come in from another airport.

Jet Fuel - Highly refined grade of kerosene used by turbine engine aircraft.

Landing Area - That part of the movement area intended for the landing and takeoff of aircraft.

Large Aircraft - An aircraft that weighs more than 12,500 lbs.

Local Operation - Aircraft operation in the traffic pattern or within sight of the tower, or aircraft known to be departing or arriving from flight in local practice areas, or aircraft executing practice instrument approaches at the airport.

LORAN C - A navigation system using land based radio signals which allows a person to tell where they are and how fast they are moving, but not how high you are off the ground. (See GPS)

MALS - Medium-intensity Approach Lighting System with Runway alignment indicator lights. An airport lighting facility which provides visual guidance to landing aircraft.

Medevac - Fixed wing or rotor-wing aircraft used to transport critical medical patients. These aircraft are equipped to provide life support during transport.

Medium Intensity Runway Lights (MIRL) - Runway lights which are not as intense as HIRLs (high intensity runway lights). Typical at medium and smaller airports which do not have sophisticated instrument landing systems.

Microwave Landing System (MLS) - An instrument landing system operating in the microwave spectrum, which provides lateral and vertical guidance to aircraft with compatible equipment. It was touted as the replacement for the ILS but never achieved this status.

Minimums - Weather condition requirements established for a particular operation or type of operation.

Movement Area - The runways, taxiways and other areas of the airport used for taxiing, takeoff and landing of aircraft, i.e., for aircraft movement.

MSL - Elevation above Mean Sea Level.

Navigational Aid (Navaid) - Any visual or electronic device that helps a pilot navigate. Can be for use to land at an airport or for traveling from point A to point B.

Nondirectional Beacon (NDB) - Non-Directional Beacon which transmits a signal on which a pilot may "home" using equipment installed in the aircraft.

Non-Precision Instrument Approach - A non-precision instrument approach provides guidance to pilots trying to land in bad weather. It does not provide the "precision" guidance of a precision instrument approach.

OAD - Oregon Aeronautics Division.

Obstruction - An object (tree, house, road, phone pole, etc) that penetrates an imaginary surface described in FAR Part 77.

Passenger Facility Charge (PFC) - Public agencies controlling a commercial service airport can charge enplaning passengers using the airport a \$1, \$2, or \$3 facility charge. Public agencies must apply to the FAA and meet certain requirements in order to impose a PFC.

Precision Approach Path Indicator (PAPI) - A system of lights located by the approach end of a runway that provides visual approach slope guidance to aircraft during approach to landing. The lights typically show green if a pilot is on the correct flight path, and turn red if a pilot is too low.

Precision Instrument Runway (PIR) - A runway served by a "precision" instrument approach landing system. The precision landing system allows properly equipped airplanes and trained pilots to land in bad weather.

Precision Instrument Approach - A precision instrument approach is a system which helps guide pilots in for a landing in thick fog and provides "precise" guidance as opposed to a non-precision approach that is less precise.

Primary Runway - That runway which provides the best wind coverage, etc., and receives the most usage at the airport.

Primary Surface - One of the FAR Part 77 Imaginary Surfaces, the primary surface is centered on top of the runway and extends 200 feet beyond each end. The width is from 250' to 1,000' wide depending upon the type of airplanes using the runway.

Rotorcraft - A helicopter.

Runway End Identifier Lights (REILs) - These are distinctive flashing lights that help a pilot identify the runway.

Runway Protection Zone (RPZ) - An area off the end of the runway that is intended to be clear in case an aircraft lands short of the runway. The size is small for airports serving only small airplanes and gets bigger for airports serving large airplanes. The RPZ used to be known as a clear zone - which was a good descriptive term because you wanted to keep it clear.

Segmented Circle - A system of visual indicators designed to show a pilot in the air which direction the airplanes fly in the landing pattern at that airport.

Small Aircraft - An aircraft that weighs less than 12,500 lbs.

T-Hangar - An aircraft storage hangar that resembles the shape of a "T."

Tiedown - A place where an aircraft is parked and "tied down." Surface can be grass, gravel or paved.

Traffic Pattern - The flow of traffic that is prescribed for aircraft landing, taxiing, or taking off from an airport.

Transitional Surfaces - One of the FAR Part 77 Imaginary Surfaces, the transitional surface extend outward and upward at right angles to the runway centerline and the extended runway centerline at a slope of 7:1 from the sides of the primary surface and from the sides of the approach surfaces.

Transport Airport - An airport designed and constructed to serve large commercial airliners. Portland International and SEATAC are good examples of transport airports.

Utility Airport - An airport designed and constructed to serve small planes. Aurora State Airport in Oregon, Nampa Airport in Idaho, or Arlington Airport in Washington are examples of utility airports.

Visual Approach Slope Indicator (VASI) - A system of lights located by the approach end of a runway which provides visual approach slope guidance to aircraft during approach to landing. The lights typically show some combination of green and white if a pilot is on the correct flight path, and turn red if a pilot is too low.

Visual Flight Rules (VFR) - Rules that govern the procedures to conducting flight under visual conditions. The term is also used in the US to indicate weather conditions that are equal to or greater than minimum VFR requirements. In addition, it is used by pilots and controllers to indicate type of flight plan.

Visual Guidance Indicator (VGI) - Equipment designed to provide visual guidance for pilots for landing through the use of different color light beams. Visual Approach Slope Indicators (VASI) and Precision Approach Path Indicators (PAPI) defined above are examples.

Wind Rose - A diagram indicating the prevalence of winds from various directions in relation to existing or proposed runway alignments.

